Quick Reference Guide

Parts Descriptions

Personal Phone



Base Unit



1 Earpiece
2 Liquid crystal display
3 Talk button
4 Speakerphone button
5 Numeral/Character buttons
6 Tone button (to switch to DTMF tone)
7 Flash/Clear button
8 Microphone
9 Multi-operation buttons
10 Voice change button
11 Off button
12 Redial button ( )
Phone book button ( )
Volume control button ( )
13 Hold/Caller ID button
14 Intercom/Text entry mode button
15 Speaker
16 Battery cover
17 Charger
18 In Use indicator
19 Page button
20 Erase button
21 Playback button
22 Auto answer button & indicator
23 Antenna
24 Skip & repeat button ( )
Volume control button ( )
Stop button ( )

■本機は日本国内用です。国外での使用に対するサービスは致しかねます。
■This product is designed for use in Japan.
Panasonic cannot provide service for this product if used outside Japan.

Personal phone (KX-FKN523)

■ To make a call

Lift the personal phone from the base unit and press 外線 (3).

➡ Dial.....To end the call, place the personal phone on the base unit or press 切 (11).

■ To receive a call

When the phone rings... ➡ Lift the personal phone from the base unit or press 外線. ➡ Talk.....To end the call, place the personal phone on the base unit or press 切.

■ To place the current call on hold

Press 保留 (13) during a call.

■ To retrieve the held call

Press 外線 or 保留.

■ To make a call using the speakerphone (Hands-free talk)

Press スピーカーホン (4). ➡ Dial. ➡ Talk to the microphone.....To end the call, place the personal phone on the base unit or press 切.

■ To receive a call with the speakerphone (Hands-free talk)

When the phone rings... ➡ With the personal phone placed on the base unit, press スピーカーホン or 外線.

➡ Talk to the microphone.....To end the call, press 切.

■ To hear recorded messages while away from home (Remote control)

Preparation before you leave home

Store a remote control number.

Press 機能 F1 # 0 0 6

➡ Enter the desired 4-digit number.

➡ Press 決定 F1.

When you leave home, press 留守 (22). (The Auto answer indicator on the base unit turns on.)

To hear messages

Dial your home phone number. ➡ While the outgoing message is played back...

➡ Enter your remote control number.

➡ Announcement ➡ Press 2.

➡ You will hear recorded messages if any.

NOTE

- This operation can be made only from telephones which can send DTMF signals.

Base unit (VE-SV06)

■ To use TAM (Telephone Answering Machine)

When you leave home, press 留守 (22).

(The Auto answer indicator (22) on the base unit turns on.)

➡ When receiving a call while TAM is activated, it answers the call automatically in Japanese, and records the incoming messages. Then, the Auto answer indicator on the base unit starts flashing.

➡ When you return home, press 留守 to play back the messages.

The Auto answer indicator turns off and the answering mode is deactivated.

To erase the message, press 消去 (20) while listening to the message you want to erase.

To play back the message while TAM is deactivated, press 聞き直し (21).

*Up to 50 messages can be recorded for approx. 12 minutes in total.

- The number after the button shows the location of the button described in the previous page.